



## **L200 Series 6 - 2019 On**

NLG Black Tail Lamp Surround Set

Fitting Instructions

Part Number: L200-19TAIL/BLACK#





## Tools Required

Cleaning Wipes

Heat Gun - Only required when ambient temperature is below 15°C to help promote adhesion between the covers and the tail lamps

## Installation Instruction

Thoroughly clean the tail lamps and surrounding area of the Series 6 L200.

Once dry use the cleaning wipes to remove any residue or remaining dirt from the tail lamps only.



Take the first tail lamp surround out of the box and peel back a small tab on each section of the adhesive tape on the rear of the surround as shown in the image below.



Offer the tail lamp surround into position on the tail lamp of the vehicle leaving the tabs exposed.



Once happy with the positioning of the tail lamp surround pull each of the tabs to fully expose the adhesive tape on the rear of the surround. Press firmly around the edge of the tail lamp surround to ensure the adhesive has made contact with the tail lamp.



If the ambient temperature of the working area is below 15°C it is recommend that application of heat is used to promote adhesion. A heat gun (shown in “Tools Required” section) is sufficient to provide enough heat to allow the adhesive tape to set.

Repeat process for second tail lamp trim.