



**L200 Series 6 - 2019 On**  
NLG Black Fog Lamp Garnish Set  
Fitting Instructions

Part Number: L200-19FOGLAMPGARNISH/MB#





## Tools Required

Cleaning Wipes

Heat Gun - Only required when ambient temperature is below 10°C to help promote adhesion between the trims and the vehicle paintwork.

## Installation Instruction

Thoroughly clean the area surrounding the fog lamps of the Series 6 L200.

Once dry use the cleaning wipes to remove any residue or remaining dirt from the painted area surrounding the fog lamps on the front bumper.



Take the first fog lamp trim out of the box and peel back a small tab on each section of the adhesive tape on the rear of the trim as shown in the image below.



Offer the fog lamp trim into position on the front bumper of the vehicle leaving the tabs exposed.



Once happy with the positioning of the fog lamp trim pull each of the tabs to fully expose the adhesive tape on the rear of the trim. Press firmly around the edge of the fog lamp trim to ensure the adhesive has made contact with the front bumper.



If the ambient temperature of the working area is below 10°C it is recommended that application of heat is used to promote adhesion. A heat gun (shown in “Tools Required” section) is sufficient to provide enough heat to allow the adhesive tape to set.

Repeat process for second trim.